









Layout Parameters

Control Edit Show Utilities View Help

Ok	Axis Lines	Simulation Locations	Simulation Objects			
Cancel	<input checked="" type="checkbox"/> X <input type="checkbox"/>	<input checked="" type="checkbox"/> Primary Target Point 	<input checked="" type="checkbox"/> Environment <input type="checkbox"/>			
Help	<input checked="" type="checkbox"/> Y <input type="checkbox"/>	<input checked="" type="checkbox"/> + Horiz <input type="checkbox"/> <input checked="" type="checkbox"/> + Vert <input type="checkbox"/>	<input checked="" type="checkbox"/> Enc <input checked="" type="checkbox"/> Splr <input checked="" type="checkbox"/> Port			
	<input checked="" type="checkbox"/> Z <input type="checkbox"/>	<input checked="" type="checkbox"/> - Horiz <input type="checkbox"/> <input checked="" type="checkbox"/> - Vert <input type="checkbox"/>	  			



259.4 X,Y,Z Pos 59.3508 -25.6991 98.7763 In X,Y,Z Deg -12.67 31.00 0.00

152% Abs Rel System Guide 24 Vert Polar F= 1.26K -N/A- -N/A- Left Right